



GENERAL SAFETY INSTRUCTIONS

Thank you for choosing a C.F. Martin fretted instrument. These instructions are meant to ensure the safe and proper use of your instrument. Please retain these instructions for future reference.

Manufacturer: C.F. Martin & Co., Inc. 510 Sycamore Street, Nazareth, Pennsylvania 18064-039 USA
customerservice@martinguitar.com www.martinguitar.com Telephone: 610-759-2837
Manufactured in Nazareth, Pennsylvania USA or Navojoa, Sonora, Mexico

Product: Martin Acoustic-Electric Guitar or Acoustic-Electric Ukulele

General Setup:

- Check that all strings are properly seated at the nut and bridge saddle.
- Tune guitar/ukulele using machine heads until brought to standard tuning.
- Turn off amplifier power.
- Plug standard 6.35 millimeter (¼ inch) guitar cable into output jack.
- Adjust preamplifier controls to desired settings

Technical Data:

- Body and Neck Materials: Wood or Wood Products
- Strings: Various metal alloys or nylon

Safety Instructions:

- After playing use a soft cloth and gently wipe the guitar down on all sides, up the neck, and go over the strings and the tuning machines.
- Avoid exposure to extreme temperatures, hot or cold. The ideal ambient temperature and humidity for the instrument is 21 degrees Celsius and 45-55 percent relative humidity.
- To avoid string breakage, do not tune more than one whole step above standard tuning.
- Take care when changing strings.
- Store in original case and check that the case latches or gig bag zippers are secure.
- Prolonged exposure to an amplified instrument may cause hearing damage. Monitor volume and length of amplified playing time.
- This instrument may have small removable parts that may be a choking hazard.

Batteries:

- Replace battery with same or equivalent one.
- Remove the batteries whenever the instrument will not be used for an extended period.



Imported and Distributed by: Westside Distribution Ltd. | 100 Fifty Pitches Road | Glasgow G51 4EB |
United Kingdom | westsidedistribution.com